

Manufacture, installation and service of fire extinguishers, fire extinguishing systems and equipment.

FOAM FIRE EXTINGUISHER

TYPE: FRSE-F6

OPERATING INSTRUCTIONS

Starting Instructions:

- Step 1: Remove the fire extinguisher from the holder!
- Step 2: Pull out the valve fuse!
- Step 3: Grab the hose with one hand and point it at the fire!
- Step 4: Squeeze the valve lever with your other hand!

Use:

The FRSE-F6 fire extinguisher is certified to extinguish the following types of fire:

- **Class A:** 34A fires of solids, especially of organic origin, the burning of which is usually accompanied by glowing.
- **Class B:** 183B fires of liquids or substances transitioning into a liquid state.

Class C: Gas fires (without testing in accordance with EN3).

Class D: Light metal fires + lithium extinguishing.

Class F: 75F – edible fats and oil fires.

How to extinguish:

Intervention with a fire extinguisher during a fire must always be carried out in the direction of the wind and the ejection jet must always be directed to the source of the fire, or to burning objects, not to the flames, while it is necessary to follow the fire at all times. Keep a sufficient distance from the fire, be careful not to transfer the flames to undesirable places with the extinguishing agent jet. To extinguish the fire, proceed from the bottom up. After extinguishing, be careful not to re-ignite.

Controls:

The device must be kept in proper technical condition. Fire extinguishers are inspected at least once a year and after each use. Inspections, repairs and filling of fire extinguishers may only be carried out by persons with professional qualifications who possess a document authorising them to perform the above activities, issued by the manufacturer of the FRSE-F6 fire extinguisher. Once every 3 years, it is necessary to carry out an examination according to § 9 of Decree No. 246/2001 Coll.



Manufacture, installation and service of fire extinguishers, fire extinguishing systems and equipment.

	WARRANTY CARD
	Headquarters:
	FIRESI s.r.o. Lidická kolonie 1108/47 586 01 Jihlava, Czech Republic, EU Reg. No. 29188024, Tax No. CZ29188024 The company is registered at the Regional Court in Brno, Section C, File 64229
Producer	Place of production:
	FIRESI s.r.o branch office Albína Krejčího 1038/1a <i>,</i> 679 61 Letovice, Czech Republic, EU
	Contact:
	Email: <u>firesi@firesi.cz</u> Phone: +420 605 222 555, E-mail: firesi@firesi.cz WEB: <u>www.firesi.cz</u>
Trade name	Portable Fire Extinguisher Foam 6 litres, extinguishing agent 100% premix FRS EXcellent 1
Product type	FRSE-F6
Serial number	
Warranty Period	24 months from the date of sale
Date of	
manufacture	
Check-out	
Date of sale:	
Stamp: Signature	::